

3-PART TOUCH-UP PEN

Waxed and varnished wood



30 ml

*Disguises superficial scratches on wood.
Suitable for scratches and blemishes on furniture and floors.*

The 3-PART TOUCH-UP PEN is ideal for disguising superficial scratches. Thanks to the 3 colour tones (from darker to lighter), you can obtain a colour close to that of your piece of furniture. Suitable for furnitures, floors, skirtings, frames with small scratches. Can be applied on varnished, waxed and oiled wood and for laminate and melamine surfaces.

INSTRUCTIONS FOR USE

Ensure the area to be treated, is free from dust.

1. Tint the wood with the selected pen in the shade closest to your piece of furniture.
2. Replace the cap and lay the pen flat or place it upside down for better preservation. Then, you can add an appropriate finish product to maintain your waxed, oiled or varnished piece of furniture.

15min

Fully dry



Tools cleaning: acetone
or Libéron Wax and
Polish Remover

LIBERON SECRET

*Keep the pen
upright with
the cap closed
and the tip
facing down for
the next use.*